

Algorithm for updating the firmware of PATRIOT 2 thermal monoculars:

1. Turn on the monocular, go to the "System" menu (folder with an "S" icon), then to the "UVC" submenu, and disable this mode. The "UVC" mode must be turned off.
2. Connect the monocular to the computer via a USB Type-C cable.
3. Copy the upgrade.pkg file for the corresponding monocular model into the "Storage" folder of the monocular's internal memory. You can download the file for the specific model from the following link:
<https://nvectech.com/downloads>
4. Disconnect the device from the computer.
5. In the PATRIOT 2 menu, go to the "System" menu (folder with an "S" icon), then to the "Update" submenu, and press "Yes".
6. Wait until the update is complete. The monocular will reboot.
7. The firmware update is complete; you can use the device.